



EZ Pan - Installation Instructions

- 1) Leave the floor opening in the foundation wall 12” wider than the finished pit width - Dimension “A” and 10” longer than finished pit length – Dimension “B”.
- 2) The front angle should be set in the center of this opening when the foundation pad is being poured.
- 3) The standard pit depth is 20” or 24” from pit floor to top of finished floor (Dimension “C”).
- 4) Pour the pit floor 6” wider than the finished pit width (Dimension “A”) and 3” longer than the finished length (including the foundation wall) dimension “B”. In addition the pit floor should slope down ½” from the rear to the front.
- 5) Set up EZ Pan. The sides will bolt to the back member, which has two holes in it. The 3” angle will be at the top on all three members and to the outside of the pit. The side members must be placed flush with the face of the foundation wall.
- 6) Make sure the EZ Pan is square. Place a 2 x 4 brace at both the middle top and the front top of the EZ Pan. Nail 2” x 4” cleats to the floor of the pit on the outside of the EZ Pan. As an option to this last step, holes can be drilled in the bottom flange of the EZ Pan and then the pan can be nailed to the pit floor.
- 7) Bulk-head the front of the EZ Pan on each side.
- 8) Pour concrete around the EZ Pan. **CAUTION:** Do not use more concrete than is normal for pit walls. Do not pour concrete too fast or bowing will occur in the pit walls.